



Detail No.	Part Name	Part No.	Price	Detail No.	Part Name	Part No.	Price
1	Outer Cone	PB2	2.75	18	Main Shaft	PB24	1.20
2	Pick-up Housing Nut	PB3	.15	19	Pinion	PB25	.50
3	Pinch Ring	PB4	.35	20	Spring	PB26	.15
4	Pick-up Housing Assembly	PB6	2.90	21	Retaining Clip	PB27	.10
5	Spool	PB8	3.95	22	Thumb Lever Sleeve	PB28	.25
6	Level Wind Plate Assembly	PB9	1.60	23	Thumb, Lever Assembly w/clip	PB30	.95
7	Crank Nut	PB10	.30	24	Cover Plate	PB32	.75
8	Lock Washer	PB11	.10	25	Thumb Lever Screw	PB33	.20
9	Crank Assembly	PB13	1.25	26	Cover Plate Screw	PB22	.15
10	Drag Star	PB14	.50	27	Gear Stem	PB37	.70
11	Drag Spring Cover	PB15	.60	28	Drive Gear Washer	PB39	.10
12	Drag Spring	PB16	.30	29	Drive Gear	PB41	.85
13	Drag Spring Washer	PB17	.15	30	Friction Washer	PB42	.10
14	Gear Stem Sleeve	PB18	.40	31	Non Reverse Ratchet	PB43	.45
16	Level Wind Yoke	PB21	.65	32	Non Reverse Pawl	PB44	.40
17	Yoke Screws (2)	PB22	.25				